checkCIF/PLATON report

You have not supplied any structure factors. As a result the full set of tests cannot be run.

THIS REPORT IS FOR GUIDANCE ONLY. IF USED AS PART OF A REVIEW PROCEDURE FOR PUBLICATION, IT SHOULD NOT REPLACE THE EXPERTISE OF AN EXPERIENCED CRYSTALLOGRAPHIC REFEREE.

Datablock: I

Bond precision:	C-C = 0.0095 A	Wavelength=0.71073	
Cell:		b=15.342(1)	
	alpha=90	beta=91.873(1)	gamma=90
Temperature:	298 К		
	Calculated	Reported	
Volume	1427.7(3)	1427.7(3)	
Space group	P 21/n	P 21/n	
Hall group		-P 2yn	
-	C15 H13 Cu N3 O S	?	
Sum formula	C15 H13 Cu N3 O S	C15 H13 Cu	1 N3 O S
Mr	346.89	346.88	
Dx,g cm-3	1.614	1.614	
Z	4	4	
Mu (mm-1)	1.677	1.677	
F000	708.0	708.0	
F000'	709.94		
h,k,lmax		8,18,16	
Nref	2663	2639	
·	0.747,0.778	0.745,0.77	79
Tmin'	0.732		
Correction method= # Reported T Limits: Tmin=0.745 Tmax=0.779 AbsCorr = MULTI-SCAN			
Data completenes	ss= 0.991	Theta(max) = 25.495	i
R(reflections) =	0.0767(1418)		wR2(reflections) = 0.1490(2639)
S = 0.984	Npar= 19)1	0.1100 (2000)
0.301	npar 13	· 	

The following ALERTS were generated. Each ALERT has the format test-name_ALERT_alert-type_alert-level.

Click on the hyperlinks for more details of the test.

```
Alert level C
RINTA01_ALERT_3_C The value of Rint is greater than 0.12
                        0.139
           Rint given
PLAT020_ALERT_3_C The Value of Rint is Greater Than 0.12 ......
                                                                      0.139 Report
PLAT048_ALERT_1_C MoietyFormula Not Given (or Incomplete) ......
                                                                     Please Check
PLAT241_ALERT_2_C High 'MainMol' Ueq as Compared to Neighbors of
                                                                         N3 Check
                       'MainMol' Ueq as Compared to Neighbors of
PLAT242_ALERT_2_C Low
                                                                        C15 Check
PLAT341_ALERT_3_C Low Bond Precision on C-C Bonds .....
                                                                   0.00954 Ang.
Alert level G
PLAT066_ALERT_1_G Predicted and Reported Tmin&Tmax Range Identical
                                                                         ? Check
PLAT883_ALERT_1_G No Info/Value for _atom_sites_solution_primary .
                                                                     Please Do !
PLAT941_ALERT_3_G Average HKL Measurement Multiplicity ......
                                                                       3.0 Low
PLAT967_ALERT_5_G Note: Two-Theta Cutoff Value in Embedded .res ..
                                                                       51.0 Degree
  0 ALERT level A = Most likely a serious problem - resolve or explain
  0 ALERT level B = A potentially serious problem, consider carefully
   6 ALERT level C = Check. Ensure it is not caused by an omission or oversight
   4 ALERT level G = General information/check it is not something unexpected
  3 ALERT type 1 CIF construction/syntax error, inconsistent or missing data
  2 ALERT type 2 Indicator that the structure model may be wrong or deficient
  4 ALERT type 3 Indicator that the structure quality may be low
  O ALERT type 4 Improvement, methodology, query or suggestion
  1 ALERT type 5 Informative message, check
```

checkCIF publication errors

```
7 ALERT level A = Data missing that is essential or data in wrong format
1 ALERT level G = General alerts. Data that may be required is missing
```

Publication of your CIF

You should attempt to resolve as many as possible of the alerts in all categories. Often the minor alerts point to easily fixed oversights, errors and omissions in your CIF or refinement strategy, so attention to these fine details can be worthwhile. In order to resolve some of the more serious problems it may be necessary to carry out additional measurements or structure refinements. However, the nature of your study may justify the reported deviations from journal submission requirements and the more serious of these should be commented upon in the discussion or experimental section of a paper or in the "special_details" fields of the CIF. *checkCIF* was carefully designed to identify outliers and unusual parameters, but every test has its limitations and alerts that are not important in a particular case may appear. Conversely, the absence of alerts does not guarantee there are no aspects of the results needing attention. It is up to the individual to critically assess their own results and, if necessary, seek expert advice.

If level A alerts remain, which you believe to be justified deviations, and you intend to submit this CIF for publication in a journal, you should additionally insert an explanation in your CIF using the Validation Reply Form (VRF) below. This will allow your explanation to be considered as part of the review process.

Validation response form

Please find below a validation response form (VRF) that can be filled in and pasted into your CIF.

```
# start Validation Reply Form
_vrf_PUBL004_GLOBAL
;
PROBLEM: The contact author's name and address are missing,
RESPONSE: ...
;
_vrf_PUBL005_GLOBAL
;
PROBLEM: _publ_contact_author_email, _publ_contact_author_fax and
RESPONSE: ...
;
_vrf_PUBL006_GLOBAL
;
PROBLEM: _publ_requested_journal is missing
RESPONSE: ...
;
_vrf_PUBL008_GLOBAL
;
PROBLEM: _publ_section_title is missing. Title of paper.
RESPONSE: ...
;
```

```
_vrf_PUBL009_GLOBAL
;
PROBLEM: _publ_author_name is missing. List of author(s) name(s).
RESPONSE: ...
;
_vrf_PUBL010_GLOBAL
;
PROBLEM: _publ_author_address is missing. Author(s) address(es).
RESPONSE: ...
;
_vrf_PUBL012_GLOBAL
;
PROBLEM: _publ_section_abstract is missing.
RESPONSE: ...
;
# end Validation Reply Form
```

If you wish to submit your CIF for publication in Acta Crystallographica Section C or E, you should upload your CIF via the web. If you wish to submit your CIF for publication in IUCrData you should upload your CIF via the web. If your CIF is to form part of a submission to another IUCr journal, you will be asked, either during electronic submission or by the Co-editor handling your paper, to upload your CIF via our web site.

PLATON version of 19/02/2022; check.def file version of 19/01/2022

